



GREAT AMERICAN SCOUNDSCAPE 1

WERSI DIRECT LIMITED

Software OAS 7.1 Revision 31 upwards required - no additional activations required.

Great American Soundscape 1

Congratulations on purchasing the new '**American Soundscape 1**' software. This new software provides Total Presets for the incredible sound of the USA!

The new registrations contained within this software do not require any additional Sound Activations. Only factory sounds are required.

WERSI Direct are pleased to present the first title in the new Registration Software series. IMPORTANT! This software only works with the OAS 7 software R7.31 upwards. You must burn these registrations to CD or copy to USB device. Contact WERSI Direct Ltd if you require a free OAS 7 software upgrade.

Loading Instructions

Loading from CD/DVD.

1. Insert your CD/DVD or USB device into the CD/DVD or USB drive.
2. Press the 'Settings' tab at the top right corner of the Main Display.
3. Press the 'OAS Database' Button in the central column of buttons.
4. A new small window will appear. Press the button marked 'Total Preset Manager' at the bottom of the centre of the new window.
5. The Total Manager will now be displayed.
6. Press the 'Import' button.
7. Select the 'Drive' that is your instruments CD/DVD or USB drive.
8. Once you have selected your CD/DVD or USB drive, the folder titled 'Great American Soundscape 1' will be displayed. The 20 Registration Total Presets are closed within this folder. Touch the folder. The 20 Total Presets will now be shown. Press the 'Select All' button.

(Create A User Group - to save your new Great American Soundscape 1 Total Presets, you may wish to create a new User Group. Press the 'New Group' button and input the name 'G.A.S 1' as the name or something similar on the virtual typewriter. Press the 'Enter' button).

9. Now that the Total Presets are highlighted in Red, press the 'Load' button.
10. A new window will be displayed. Please select a free slot to save the 20 Total Preset Registrations and press 'Save'. Please be aware that any Presets that currently occupy any of the slots that you select, will be overwritten. Please take care to select only free / vacant slots.

Registration Recall

Using Quickload

1. From the Main Display press the 'Quickload' button.
2. Press the 'Presets' button at the top of the screen (Left hand side)
3. Make sure that you have 'User Presets selected for the menu displaying the Preset content of your OAS instrument.
4. Scroll down to the new '**G.A.S 1**' registrations' in the slots that you have saved them to.
5. Select the Total Preset registration from the list and press the large 'Load' button in the bottom right hand corner.

Using 'Easy Preset' Function

1. From the Main Display press the 'Easy Preset' button.
2. Select the User Bank on the right hand side to navigate to the new registration Total Presets.
3. Simply select the desired registration displayed on the Easy Preset display for the entire instrument to be loaded instantly!

Registration Overview

1. 1920's Swing Clarinet
2. 1920's Swing Violin
3. Buddy Holly Ballad
4. CD Jazz Guitar + Vibes
5. Cocktail Piano
6. Good, Bad & Ugly
7. Haunting English Horn
8. Hollywood Strings Pitz
9. Hollywood Strings
10. Jazz Guitar + Flute
11. Larry Adler
12. Liberace Piano
13. NASA Fanfare
14. Once upon a time in America
15. Once upon a time in the west
16. Piano with sad Strings.
17. Piano+Vibes & Sax Split
18. Sad Trombone
19. Sandman Scat
20. Trombone & Deep Brass



WERSI