



WERSI

SYNTHS, PADS & LEADS

For OAS 7 Instruments

Loading Instructions:

Registrations (Total Presets)

1. Insert your CD/DVD or USB device into the CD/DVD or USB drive.
2. Press the 'Settings' tab at the top right corner of the Main Display.
3. Press the 'OAS Database' Button in the central column of buttons.
4. A new small window will appear. Press the button marked 'Total Preset Manager' at the bottom of the centre of the new window.
5. The Total Manager will now be displayed.
6. Press the 'Import' button.
7. Select the 'Drive' that is your instruments CD/DVD or USB drive.
8. Once you have selected your CD/DVD or USB drive, the Synths, Pads and Leads Registration Total Presets will be displayed.
Press the 'Select All' button.
9. Now that the Total Presets are highlighted in Red, press the 'Load' button.
10. A new window will be displayed. Please select a free slot to save the Synths, Pads and Leads Total Preset Registrations and press 'Save'. Please be aware that any Total Presets that currently occupy any of the slots that you select, will be overwritten. Please take care to select only free / vacant slots.

Registration Recall Using Quickload

1. From the Main Display press the 'Quickload' button.
2. Press the 'Presets' button at the top of the screen (Left hand side)
3. Make sure that you have 'User Presets selected for the menu displaying the Preset content of your OAS instrument.
4. Scroll down to the new 'Synths, Pads and Leads registrations' in the slots that you have saved them to.
5. Select the Total Preset registration from the list and press the large 'Load' button in the bottom right hand corner.
Using 'Easy Preset'
1. From the Main Display press the 'Easy Preset' button.
2. Select the User Bank on the right hand side to navigate to the new registration Total Presets.
3. Simply select the desired registration displayed on the Easy Preset display for the entire instrument to be loaded instantly!

Total Presets:

1. 80's Lead Angel
2. Dirty Brass Filterz
3. 80's Galaxy Lead
4. 80's Light Lead
5. 80's Synth Computer
6. 80's Twitch Lead
7. 90's Pop Lead
8. Dance Piano Swede
9. Dance Galaxy Piano
10. Ethereal Pad 1
11. Ethereal Pad 2
12. Ethereal Pad 3
13. Eurovision Clude Lead
14. Fleetwood Lies Lead
15. Ghost Pad
16. Kylie Lovers Lead
17. Kylie Mental Oriental Lead
18. Lords Chase Delay
19. Lost Chill Pad
20. Mellow 80's LEad
21. Modern Lead
22. Mysterious Tension Screamer
23. Oakenfold Big Synth

Total Presets:

24. Oakenfold Low Filter Brass
25. Oberheimer Pad
26. Phaser Dance Lead
27. Power Swell PAD
28. Pretty Delay Piano
29. Relaxing Synth 1
30. Relaxing Synth 2
31. Rhianna Calvin H Sound
32. RiRi Girls World Synth
33. Sash D50 Screwball
34. Soundscape Ball
35. Synth Bellend
36. Synth Brass Obsession
37. Tron Brass
38. Vangelis Movie Pad
39. WOWT Mars Radio Synth

SPECIAL NOTES:

Created by WERSI Direct Ltd. Programming by Robert New.

CONTACT DETAILS

WERSI DIRECT LTD:
Tel: 0800 084 2013
www.wersidirect.com
info@wersidirect.com